

890 Quickstart Manual

890CS/CD (Common Bus) Drives Frames B, C & D with STO SIL3/PLe

HA501027U000 Issue 3

1) **What is Safe Torque Off (STO)?**

It is an electronic means of preventing the 890 drive from delivering torque and power to its connected motor. The 890 drive contains this feature as standard. It is a two channel, hardware implemented system. It has the highest possible safety rating for a variable speed drive. It is certified by BGIA, the German Trades Association for Industrial Safety, to Performance Level e (PLe) for a category 3 implementation to EN ISO 13849-1 with an equivalent Safety Integrity Level 3 (SIL 3).

All STO connections are made at terminal block X11.

2) **Where Could STO be Used?**

In safety control schemes for safety ratings up to category 3 PLe or SIL3. To replace expensive but less reliable drive output contactors, including for emergency stop purposes. The 890 STO function can also be used to implement Safe Stop 1 (SS1).

3) **To Use the STO Function - What Should I Do Next?**

Read and observe all the requirements in the STO chapter 6 of the Engineering Reference Manual contained on the supplied CD, use the appropriate standards and risk assessments.

4) **Replacing a NON STO Drive OR the STO Function is Not Required - What Should I Do Next?** Simply disable the STO function by Linking –

X11/01 and X11/03 to X14/03 (24V) and separately link X11/02 OR X11/04 to X14/04 (0V).
The rest of this quick start manual then applies.

5) **On Start Up the MMI Displays “ ***Tripped*** SAFE TORQUE OFF” or on a 6511 MMI “^ASTO ” . Why?**

Because no connections to X11/01 OR X11/03, they are at 0V, the STO feature has been enabled i.e. failed safe. Simply disable the STO feature by fitting the links described in item 4) above.

© Copyright 2011 Parker Hannifin Manufacturing Ltd.

All rights strictly reserved. No part of this document may be stored in a retrieval system, or transmitted in any form or by any means to persons not employed by a Parker Hannifin Manufacturing Ltd., without written permission from Parker Hannifin Manufacturing Ltd. Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions. Parker Hannifin Manufacturing Ltd., cannot accept responsibility for damage, injury, or expenses resulting there from.

Contents

| | <i>Page</i> |
|---|-------------|
| Safety | 4 |
| Hazards to Personnel | 4 |
| Application Risk | 4 |
| • Risk Assessment | 5 |
| • Accessibility | 5 |
| • Protective Insulation | 5 |
| • RCDs | 5 |
| Introduction | 7 |
| About this QuickStart | 7 |
| • SSD_Rail | 8 |
| Installation | 9 |
| Dimensions | 10 |
| • Ventilation | 10 |
| • Environmental Conditions | 10 |
| Overview | 11 |
| 890CS Power Connections | 12 |
| 890CD Power Connections | 13 |
| SSD_Rail Connections | 14 |
| • Busbar Installation | 14 |
| 890CS Control Connections | 15 |
| 890CD Control Connections | 16 |
| 890CD Feedback Connections | 17 |
| Drive Start-up | 18 |
| Before Applying Power: | 18 |
| Powering-up the 890CS | 19 |
| Powering-up each 890CD | 19 |
| 890CD Set-up | 19 |
| Motor Data | 19 |
| Quick Setup Parameters | 20 |
| Autotune | 20 |
| Running in Local | 21 |
| Running in Remote | 21 |
| Appendix A: Using the 6511 Keypad | 22 |
| The Menu Structure | 23 |
| • 890CS | 23 |
| • 890CD | 24 |
| Appendix B: Using the 6901 Keypad | 25 |
| The Menu Structure | 26 |
| • 890CD | 26 |
| • 890CS | 27 |
| Appendix C: Analog and Digital I/O | 28 |
| 890CD Control Connections | 28 |
| 890CD Control Terminals | 29 |
| 890SD Control Terminals | 30 |
| 890CS Control Terminals | 31 |
| Appendix D: Electrical Ratings | 32 |
| 890CS Common Bus Supply | 32 |
| 890CD Common Bus Drive | 33 |
| Appendix E: Compliance | 35 |
| EMC Emissions | 35 |
| EMC Connections | 35 |
| Planning Cable Runs | 36 |

Safety


IMPORTANT Please read this information *BEFORE* installing the equipment.




This manual is for anyone installing, operating and servicing this unit.




You must be technically competent to install and operate this unit.




Before working on the unit, isolate the mains supply from terminals L1, L2 and L3 and wait 3 minutes.



Disconnect the unit from circuits when doing high voltage resistance checks.



The unit must be **permanently earthed** due to the high earth leakage current.



The drive motor must be connected to an appropriate safety earth.



Electrostatic discharge sensitive parts : observe static control precautions.



Copy existing 890 parameters to any replacement 890 unit

Hazards to Personnel

WARNING

This equipment can endanger life through rotating machinery and high voltages. Failure to observe the following will constitute an **ELECTRICAL SHOCK HAZARD**.

Metal parts may reach a temperature of 70 degrees Centigrade in operation.

Before working on the equipment, ensure isolation of the mains supply from terminals L1, L2 and L3. The equipment contains high value capacitors which discharge slowly after removal of the mains supply. Wait for at least 3 minutes for the dc link terminals (DC+ and DC-) to discharge to safe voltage levels (<50V). Measure the DC+ and DC- terminal voltage with a meter to confirm that the voltage is less than 50V.

Do not apply external voltage sources (mains supply or otherwise) to any of the braking terminals (DBR+, DBR-, DC+, INT or EXT).

Application Risk

The specifications, processes and circuitry described herein are for guidance only and may need to be adapted to the user's specific application.

Parker SSD Drives does not guarantee the suitability of the equipment described in the Manual for individual applications.

Risk Assessment

Under fault conditions, power loss or other operating conditions not intended, the equipment may not operate as specified. In particular:

- The motor speed may not be controlled
- The direction of rotation of the motor may not be controlled
- The motor may be energized

If the STO feature of the 890 drive is to be used, the user must undertake a risk assessment for the application. The user must then verify that their design, which includes the 890 drive, satisfies the Performance Level (PL) or Safety Integrity Level (SIL) required by the risk assessment.

Under no circumstances must the STO feature be used without first reading and fully understanding chapter 6 (Safe Torque Off) of the Engineering Reference Manual. All safety warnings therein must be observed.

Accessibility

All live power terminals are IP20 rated only, since the equipment is intended to be installed within a normally-closed cubicle or enclosure, which itself requires a tool to open.

Protective Insulation

- All control and signal terminals are SELV, i.e. protected by double insulation. Ensure all wiring is rated for the highest system voltage.

NOTE *Thermal sensors contained within the motor must be single/basic insulated.*

- All exposed metalwork in the Drive is protected by basic insulation and bonding to a safety earth.

RCDs

Not recommended for use with this product. Where their use is mandatory, use only Type B RCDs (EN61009).

Caution

This is a product of the restricted sales distribution class according to IEC 61800-3. It is designated as “professional equipment” as defined in EN61000-3-2. Permission of the supply authority shall be obtained before connection to the low voltage supply.

Introduction

The 890 Common Bus units are designed for speed control of standard ac 3-phase motors. The common bus scheme consists of one 890CS (Common Bus Supply) and one or more 890CD (Common Bus Drives).

3-phase power is supplied to the 890CS. Power (DC) is bussed from the 890CS to all 890CDs using the **SSD_Rail** busbar system. A motor is connected to each 890CD unit.

- Control the system remotely using configurable analogue and digital inputs and outputs.
- Control the 890CD locally using the 6511 Keypad.
- Use the Design System Explorer Configuration Tool (DSE 890) to give access to 890CD parameters, diagnostic messages, trip settings and application programming.
- Fit Options to the 890CD to give serial communications and closed loop speed control.

IMPORTANT *Motors used must be suitable for Inverter duty.*

About this QuickStart

This QuickStart will:

- Familiarise you with the terminals and operation of the unit.
- Provide ***basic** installation details and a quick set-up procedure.
- Show you how to Autotune the 890CD and start the motor.

** Because the 890 is a system product and we have no knowledge of your application, we detail the quickest way to power-up the drive using a simple earthing scheme with minimal control wiring. Refer to the full Engineering Reference Manual for items not covered in this QuickStart.*

Provided with every 890 unit is a:

- Quickstart
- Compact disk containing the Engineering Reference Manual and DSE Configuration Tool
- 890 Installation Kit and instruction leaflet
- 6511 Keypad
- Customer-ordered Options


This QuickStart assumes that:

- You are a qualified technician with experience of installing this type of equipment.
- You are familiar with the relevant standards and Local Electric Codes (which take precedence).
- You have read and understood the Safety information provided at the front of this QuickStart.
- You realise that this guide contains only basic information and that you may need to refer to the Engineering Reference Manual to complete your installation.
- You are not using the Safe Torque Off (STO) feature of this product and that you will disable it as instructed in this QuickStart manual.
Safety Note – Use of the STO feature requires full compliance with the STO chapter 6 of the Engineering Reference Manual to which the user must first refer.

SSD_Rail


Since the height and depth of every module is the same, it is very convenient to assemble drives of varying frame sizes into one common bus system. Typically they are installed side-by-side.

SSD_Rail is an innovative busbar system that connects the DC+ and DC- terminals of all drives on a common bus without the use of wire.



Installation

A simplified installation is shown below. This installation is **not** EMC compliant. For European installations and countries with EMC legislation refer to the 890 Engineering Reference Manual, Appendix C.



KEY

- B** Back-plate
- C** Cubicle
- Supply
- G** Protective Earth/Ground
- K** Motor (M1, M2, M3)
- 3Ø Power
- L** Supply Cable (L1, L2, L3)
- P** Fuse or circuit breaker
- R** AC Line Reactor
- T** Control Wiring Terminals

890 Installation Kit


The 890 Installation Kit is shown in the diagram attached to the bottom of the 890CD units. It can also be fixed to the top of the unit.

The kit provides several options for earth/ground connections. It also includes the brackets for DIN rail mounting the unit. Refer to the instructions in the kit and use the appropriate parts.

* Permanent Earthing

The unit must be **permanently earthed** according to EN 50178: A cross-section conductor of at least 10mm² is required. This can be achieved either by using a single conductor (PE) or by laying a second conductor though separate terminals (PE2 where provided) and electrically in parallel.

Dimensions




Dimensions are in millimeters (X: Power Bracket - 890 Installation Kit, Y: Control Bracket)

The units must be installed in a cubicle. Mount the drive using the keyholes and slots or on a 35mm DIN rail using the 890 Installation Kit supplied.

IMPORTANT: *The 890CS Common Bus Supply is normally mounted to the left of the 890CD Common Bus Drive(s). However, for 890CS Frame D, mount the 890CS between the 890CD units to share the load evenly if the total current draw on the DC busbar will exceed 140A. Connect to the left and right busbar terminals separately. The busbar is rated for operation at 140A. Do not exceed 140A.*

Ventilation


The drives can be mounted side-by-side with no clearance. A minimum of 150mm (6 inches) free-air space must be allowed at the top and bottom of each drive. If mounting drives above or below other equipment, the top and bottom distances should be added for overall clearance between drives.



Environmental Conditions

| | |
|-------------------------------|--|
| Operating ambient temperature | 0°C to 45°C (32°F to 113°F) |
| Enclosure rating | IP20 – UL(cUL) Open type |
| Atmosphere | Dust free, non flammable, non-corrosive, <85% humidity, non-condensing |

Overview



890CS Power Connections

1 Connect 3-phase power in any order to L1, L2, L3.
Maximum wire sizes:

- Frame B1: 10mm²/8AWG
- Frame B2: 16mm²/4AWG
- Frame D1: 50mm²/ 1/0AWG
- Frame D2: 95mm²/ 4/0AWG

- A 3% line reactor **MUST** be fitted.
- Use branch circuit protection (circuit breaker and/or fuses)


Refer to Appendix D for Drive rating details

2 Connect the earth/ground wire to the bottom ground bracket.
Maximum wire sizes:

- Frame B1: 10mm²/8AWG
- Frame B2: 16mm²/4AWG
- Frame D1: 50mm²/ 1/0AWG
- Frame D2: 95mm²/ 4/0AWG

3 An External Braking Resistor is optional. Connect it between DBR+ and DBR- for high inertial loads. We recommend using a thermal overload switch to protect the braking circuit.

DO NOT apply external voltage sources (mains supply or otherwise) to the braking terminals.



890CD Power Connections

4 Connect motor leads to M1, M2, M3.

Maximum wire sizes:

Frame B: 4mm²/12AWG

Frame C: 10mm²/8AWG

Frame D: 16mm²/4AWG

- Connect the earth/ground wire from the terminal box of the motor directly to the bottom ground bracket.

Maximum wire sizes:

Frame B: 4mm²/12AWG

Frame C: 10mm²/8AWG

Frame D: 16mm²/4AWG

- If not using shielded cable, run motor leads in an enclosed metal conduit grounded at both ends

6 Connect motor thermal switch or thermistor to Th1, Th2. Drive will trip when the thermal switch opens, or when the thermistor resistance exceeds 4kΩ maximum (PTC Type A : IEC 34-11 Part 2)

- If the motor does not have a protective device (thermistor), jumper these terminals. The drive needs the thermistor inputs connected for it to run.

7 Connect the 24V DC brake supply to terminals 1 and 2, and connect the brake terminals to 3 and 4. The brake coil is energized when the drive runs.


5 Connect the earth/ground wire to the bottom ground bracket.

Maximum wire sizes:

Frame B: 4mm²/12AWG

Frame C: 10mm²/8AWG

Frame D: 16mm²/4AWG



SSD_Rail Connections

WARNING

During commissioning, remove the fuses (or trip the circuit breaker) on your 3-phase supply. Make sure the power is OFF, and that it cannot be switched on accidentally whilst you are working.

Caution

All 890 units connected to the DC bus must be rated for the same 3Ø operating voltage.


The following items are available from Parker SSD Drives:

- Busbar : Part No. BH465850 - 1m length, 10mm x 3mm copper
- Busbar Insulator : Part No. BC465938U200 - 200mm length

The bus bar is rated at 140 Amps.

Busbar Installation

1. Simply select two correct lengths of the busbars and drop them in the slots shown in the close-up top view. Secure with two screws (2.0 Nm), shown by the arrows. Fit insulating sleeve to any busbar that protrudes from the units.
2. **For your safety and EMC compliance:**
 - ◆ **Busbar:** both ends of the bar must be inserted into a terminal – with NO OVERHANG if a terminating piece.
 - ◆ **Insulator:** Fit this to all busbar external of the unit. It should butt-up to the sides of each unit. Press it firmly down onto the busbar for complete protection.
3. Close all Busbar Terminal Covers. They snap shut.



890CS Control Connections

A Voltage Selection

Use a small slotted screwdriver to set the rotary switch S1 to match the voltage of the incoming 3-phase power.

NOTE: This is factory set to 500V. This MUST be set to the incoming line voltage.

B 24V Aux Supply

- Connect a 24VDC power supply across terminals X01/01 and X01/04 (mandatory).

24VDC in terminal X01/01
0VDC in terminal X01/04


- Run 24VDC power to supply 890CDs (optional).

24VDC out terminal X01/02
0VDC out terminal X01/03

C Sequencing

Connect a volt-free contact

- RUN (maintained contact) across terminals X02/01 and X02/03



Terminals X04/01 & X04/02
X04/05 & X04/06

If the supply to these volt-free relays is >25Vac rms or >60V dc, you must provide an appropriate fusing system of 10A for the supply to these digital outputs to comply with UL Earthing Requirements.

Indication

- Terminals X02/05 and X02/06 provide an analog output proportional to Input Current or Power.
- Terminals X04/01 and X04/02 provide a Health warning contact signalling an impending fault.
- Terminals X04/05 and X04/06 provide a Health Trip contact signalling the drive has faulted.

890CD Control Connections

A Speed Reference

- Connect a 10kΩ potentiometer at terminal block X12 (Analog I/P 3)

High (CW): terminal X12/08
 Wiper: terminal X12/04
 Low (CCW): terminal X12/01

- Connect the shield to earth/ground at the bottom ground bracket

OR

- External 2-wire speed reference between terminals X12/01(-) and X12/04(+)
- Connect the shield to earth ground at the bottom ground bracket

B Sequencing

Connect volt-free contacts as required

- RUN (maintained contact) terminal X14/03 and terminal X15/02


C Safe Torque Off

To disable STO:

- Connect X14/03 to X11/01 and X11/03
- Connect X14/04 to X11/04

To use the STO feature the user must read and fully understand chapter 6 of the Engineering Reference Manual.

The control terminals will accept a single wire of size 1.5mm²/16AWG. For two wires per terminal, use smaller gauge wire such as 0.5mm²/22AWG.



Analog

- SPEED FEEDBACK
10V = ±100% speed at terminal X12/0 6
- TORQUE FEEDBACK
10V = ±200% torque at terminal X12/07
- ANALOG COMMON
0V at terminal X12/0 1

Digital

- DRIVE HEALTH
Relay dry contact (24V rated) at terminal X14/01 and terminal X14/02
- RUNNING
24V sourcing output at terminal X15/08
- ZERO SPEED
24V sourcing output at terminal X15/09
- DIGITAL COMMON
0V at terminal X14/04

This is a basic connection diagram.
 For more detailed information on control connections, refer to Appendix C.

890CD Feedback Connections

This section is only for closed loop vector and induction servo applications. Skip this page if there is no encoder or resolver mounted on the motor.

Incremental Pulse Encoders

The default settings for the drive are for 2048 line, quadrature, incremental pulse encoders with differential outputs operating from a 10VDC supply.

- Z channel (Marker pulse) connections are not necessary for running the drive, but inputs are provided for positioning and servo applications. The supply voltage to the encoder is set in the Quick Setup menu. Range 10 VDC to 20 VDC

Use the Keypad to set the following options:

Supply Voltage - PULSE ENC VOLTS (S17)

Number of lines per revolution - ENCODER LINES parameter (S18)

* Encoder direction - ENCODER INVERT (S19)


** Used to match the encoder direction to the motor direction. When TRUE, changes the sign of the measured speed and the direction of the position count. It is necessary to set up this parameter when in CLOSED-LOOP VEC mode, as the encoder direction must be correct for this mode to operate.*

Using other types of encoders requires the DSE Configuration Tool and the setting of other parameters. Refer to the 890 Engineering Reference Manual for details of these parameters.

Use 3-pair or 4- individually shielded cable; Belden model 8777 equivalent.



| OPTION F Terminal Block | |
|-------------------------|------------|
| 01 | Shield |
| 02 | Supply - |
| 03 | Supply + |
| 04 | Channel Z/ |
| 05 | Channel Z |
| 06 | Channel B/ |
| 07 | Channel B |
| 08 | Channel A/ |
| 09 | Channel A |



Drive Start-up

Before Applying Power:

- Read the Safety section at the front of the QuickStart.
- Ensure that all local electric codes are met.
- Check for damage to equipment.
- Check for loose ends, clippings, filings, drilling swarf etc. lodged in the drive and system.
- Check all external wiring circuits of the system - power, control, motor and earth connections.
- Ensure that unexpected rotation of the motor in either direction will not result in damage, bodily harm or injury. Disconnect the load from the motor shaft, if possible.
- Check the state of the Motor Thermistor and Brake Resistor connectors. Check external run contacts are open. Check external speed setpoints are all at zero.
- Ensure that nobody is working on another part of the system which will be affected by powering up.
- Ensure that other equipment will not be adversely affected by powering up.
- Check motor stator connections are correctly wired for Star or Delta as necessary for drive output voltage.
- Check motor stator connections are correctly wired for Star or Delta as necessary for drive output voltage.
- Ensure that the SSD_Rail has been correctly installed and securely fastened.
- On the 890CS drive, set the line voltage on rotary switch S1.
- Check that the STO feature has been disabled. See page 14 of this Quickstart Manual.
- DANGER: some motors and control methods are not suitable for use with STO. Refer to chapter 6 of the Engineering Reference Manual for full details.

If all connections have been checked, it is time to **POWER-UP the drive**

Powering-up the 890CS

Initial Power-up Sequence

1. **A three-phase supply is NOT necessary at this stage.**
2. Before applying 3-phase power, ensure that an appropriate 3% line reactor has been fitted. This is a pre-requisite of any input section.
3. Ensure ENABLE is low, (0V), X02/03 (connect a temporary switch or remove terminal block).
4. Switch on the 24VDC auxiliary power supply to the 890CS drive. If daisy-chained to the 890CD's, these will also power-up in Remote Mode and display a DCLO trip (expected).
5. Check the voltage setting on the 890CS keypad (it will appear as soon as you apply power) and ensure it matches your incoming line voltage. If not, switch off the 24VDC, correct the setting of rotary voltage selector switch S1 then switch the 24VDC back on.
6. There are no parameters to set-up the 890CS unit.
7. Check that the run signal on each 890CD is inactive, unless motor rotation is required at this time.
8. **At this stage, apply 3-phase power to the 890CS.** Changing ENABLE to high (24V OUT), will cause the 890CS to power up the SSD_Rail.
9. Pressing the STOP key on each 890CD will clear the DCLO trip.

Normal Power-up Sequence

The simplest way to power up the 890CS is to connect the ENABLE input to 24V OUT then power up the 3-phase power and the 24VDC auxiliary power supply together. The 890CS will immediately power up the SSD_Rail.

Powering-up each 890CD

1. By now, the whole system has power applied to it.
2. The following sections cover getting the pertinent motor data, setting the appropriate parameters (using the keypad) and performing an autotune.

890CD Set-up

Refer to Appendix A if using the 6511 keypad supplied with the drive. Appendix B contains information about the 6901 keypad that displays menu and parameter names in English.

Motor Data

Before attempting to set up the drive, you will need some motor information. This is found on the motor nameplate. The information you will need is listed below:

| | | |
|----------------|----------------|----------------------------|
| Base Volts | Base RPM | No load amps (mag current) |
| Base frequency | Full load amps | Connection (star or delta) |

Quick Setup Parameters

The following is a list of the Quick Setup parameters you must check before starting the drive. Set only the ones marked with “x” in the table below, under the intended mode of operation.

| | | | V/Hz | SV | Vector |
|-----|-----------------|---|------|----|--------|
| S1 | Control Mode | Select the intended operating mode | x | x | x |
| S2 | Max Speed | Motor RPM at full process speed | x | x | x |
| S7 | V/F shape | Usually Linear. Choose fan curve only for fans | x | | |
| S9 | Motor Current | Motor full load current from motor nameplate | x | x | x |
| S14 | Motor Base Freq | Motor nameplate frequency | x | x | x |
| S15 | Motor Voltage | Motor nameplate voltage | x | x | x |
| S16 | Nameplate RPM | Motor nameplate RPM | x | x | x |
| S17 | Motor Poles | See Note | | x | x |
| S19 | Pulse Enc Volts | set between 10-20V to match encoder | | | x |
| S20 | Encoder Lines | Pulses per Revolution of encoder | | | x |
| S21 | Encoder Invert | Changes polarity of encoder feedback | | | x |
| S22 | Autotune Enable | Drive will Autotune if started | | x | x |
| S24 | Mag Current | Enter the No-Load Amps from the motor nameplate | x | x* | x* |

* if performing a Stationary Autotune.


NOTE Some of the parameters are product code dependent, that is, they are different for each frame size and power rating. For example, the unit will be set for either 50Hz or 60Hz operation:

Motor Poles for 60Hz 2 poles = 3600 rpm, 4 poles = 1800 rpm, 6 poles = 1200 rpm
 Motor Poles for 50Hz 2 poles = 3000 rpm, 4 poles = 1500 rpm, 6 poles = 1000 rpm

Autotune

This section is only for operating in Sensorless or Closed-loop Vector modes. If the drive is in V/Hz mode, Autotune is unnecessary and will not Enable.

- Ensure that MAX SPEED is greater than NAMEPLATE RPM for a successful autotune.
- In the QUICK SETUP menu, set AUTOTUNE ENABLE (S22) to TRUE.
- On the 890CD keypad select LOCAL mode. Set the local setpoint, OP 1, to 0.0%.
- Press the green RUN button. The drive will begin autotuning. The drive will stop without errors if autotune is successful.
- Go to SYS::SAVE::APP and UP arrow to save your settings.



Running in Local


- On the 890CD keypad select LOCAL mode. The display will show the Local Setpoint : 0.0%
- Use the UP arrow to set a Local Setpoint, say 20%.
- Press the green RUN button. The motor will accelerate to the desired speed and maintain it. Adjust RAMP ACCEL TIME (S3) in Quick Setup to the desired level.
- Press the red STOP button. The motor will decelerate to a stop. Adjust RAMP DECEL TIME (S4) in Quick Setup to desired level. If the drive trips on Overvoltage, extend the RAMP DECEL TIME or connect a braking resistor. Refer to the 890 Engineering Reference Manual.

Go to SYS::SAVE::APP and UP arrow to save your settings Values are stored during power-down.

Running in Remote

- On the 890CD keypad select REMOTE mode. The display will show the remote Setpoint : ?.?% (The value displayed depends on the external speed reference).
- Dial in a speed setpoint using the Speed potentiometer until the display reads 20%.
- Start the drive by closing the Start contact between terminal X14/03 and terminal X15/02. The motor will accelerate to the desired speed and maintain it. Adjust RAMP ACCEL TIME (S4) in Quick Setup to the desired level.
- Open the Start contact. The motor will decelerate to a stop. Adjust RAMP DECEL TIME (S4) in Quick Setup to desired level. If the drive trips on Overvoltage, extend the RAMP DECEL TIME or connect a braking resistor. Refer to the 890 Engineering Reference Manual.

Go to SYS::SAVE::APP and UP arrow to save your settings Values are stored during power-down.



Appendix A: Using the 6511 Keypad





The 6511 is the keypad that comes as standard with any 890 product. It is a one-line backlit LCD with units and symbols for different functions. It can be used to setup and configure the 890. It can also be used to operate the drive in Local mode from its Start and Stop buttons.

From power-up, the keypad displays the Software Version, and then times-out to show the Remote Setpoint, as shown opposite.




To change Operating Mode:


On the 890CS you can change between local and remote mode from any point on the MMI. However, on the 890CD you must be at the top of the MMI, showing the software version, before you can change between local and remote modes.

| Mode | Action |
|-----------------|---|
| Remote to Local | Hold the Stop key  down until LOC is displayed  |
| Local to Remote | Hold the Stop key  down until LOC and  are removed |

To display the software version (890CD):

Press  repeatedly to display software version.

To display the software version (890CS):

Press and hold  to display software version.

To display the line voltage rating (890CS):

As above, then press  or  to toggle between software version and line voltage rating.

To Start in Local Mode:

Press 


To Stop in Local Mode:

Press 

Displays diagnostics, parameter and trip information

Displays the units for the value:
S for seconds, **A** for current in Amps, **V** for voltage in Volts, **%** for percentage, **Hz** for frequency in Hertz

Indicates motor shaft direction (890CD), or DC link enabled (890CS)




Indicates Local Mode (Remote Mode when not visible)

The Menu Structure

890CS

The main menu for the 890CS is shown below. The unit will initialise in Remote Mode from factory conditions. The Keypad will display the Output Power (%). This is the first of five diagnostics.



Welcome Screen Displays the software version of the unit

*From the Welcome Screen, the display times-out (alternatively you can press the **M** key) to show the first of 5 diagnostics:*

Output Power As a percentage of nominal full power for the selected input voltage

Heatsink Temp The heatsink temperature in Centigrade

Supply Frequency The real time frequency of the input supply in Hz

DC Link Volts $V_{ac} (rms) \times \sqrt{2} = dc \text{ link Volts}$ (when motor stopped)

Input Current The real time input current in Amps

890CD

The main menus for the 890CD are shown below. Each menu contains parameters.



This is the power-up welcome screen. If a different screen appears, press E a few times to return to this screen




Press the M key to get to OPERATOR menu



DOWN arrow to get to the DIAGNOSTICS menu



DOWN arrow to get to the QUICK SETUP menu



DOWN arrow to get to the SYSTEM menu

NOTE Refer to the Engineering Reference Manual for a list of available parameters.

How to Edit a Parameter

Press **M** to enter the SET::QUICKSETUP menu.

Scroll through the parameters using the **▲** and **▼** keys.

Press **M** to select a parameter for editing.

Increment/decrement the parameter value using the **▲** and **▼** keys.

Press **M** to exit the parameter.

Appendix B: Using the 6901 Keypad

The 6901 keypad has a two-line backlit LCD display with units and symbols. It can be used to setup and configure the 890 in plain language. It can also be used to operate the drive in Local mode from its Start and Stop buttons, Jog and reverse.

To display the Software Version and Voltage Rating:

Press **E** repeatedly to display the Welcome Screen

Press **M** to return to the Menu

To Start in Local Mode:

Press **I**

To Stop in Local Mode:

Press **O**



SEQ and REF LEDs are On when in Local mode

| | | | | |
|---------------------|-------------------------|--------------------------------|-----------------------------|--------------------------|
| Menus : | E exit a menu | M sub-menu or parameter | ▲ scroll up | ▼ scroll down |
| Parameters : | E exit parameter | M make writable | ▲ previous parameter | ▼ next parameter |
| Edit | E stop editing | M show PREF (hold) | ▲ increment value | ▼ decrement value |

To change Operating Mode:


From power-up, the keypad displays the Software Version, and then times-out to show the Remote Setpoint.

| Mode | Action |
|-----------------|--|
| Remote to Local | Toggle between modes using the L/R key L/R SEQ and REF LEDs are On when in Local |
| Local to Remote | Toggle between modes using the L/R key L/R SEQ and REF LEDs are Off when in Remote |

The Menu Structure

890CD

The main menus for the 890CD are shown below. Each menu contains parameters.




NOTE Refer to the Engineering Reference Manual for a list of available parameters.

890CS

The unit will initialise in Remote Mode from factory conditions.

The Keypad will display the Output Power (%). This is the first of five diagnostics.



Welcome Screen Displays the software version of the unit

From the Welcome Screen, the display times-out to show the first of 5 diagnostics:

Output Power As a percentage of nominal full power for the selected input voltage

Heatsink Temp The heatsink temperature in Centigrade

Supply Frequency The real time frequency of the input supply in Hz


DC Link Volts $V_{ac} (rms) \times \sqrt{2} = dc \text{ link Volts (when motor stopped)}$

Input Current The real time input current in Amps

Appendix C: Analog and Digital I/O

890CD Control Connections


The terminal function names apply to the factory shipping configuration. These terminals may have different functions if the configuration has been modified using DSE.



890CD Control Terminals


The terminal function names apply to the factory shipping configuration. These terminals may have different functions if the configuration has been modified using DSE.


- Analog I/O connector is X12
- Analog I/O resolution is 12 bit plus sign
- Digital I/O connector is X15
- Digital I/O is 24VDC, sourced, active high



| Terminal | Name | Range | Description |
|--------------------|------------|--------------------------------|---|
| ANALOG I/O | | | |
| X12/01 | 0V | | 0V reference for analog I/O |
| X12/02 | AIN1 | 0-10V, ±10V | Analog Input 1 Configurable (default = diff I/P +) |
| X12/03 | AIN2 | 0-10V, ±10V | Analog Input 2 Configurable (default = diff I/P -) |
| X12/04 | AIN3 | ±10V, 0-10V, 0-20mA, 4-20mA | Analog Input 3 Configurable (default = remote setpoint I/P) |
| X12/05 | AIN4 | ±10V, 0-10V, 0-20mA, 4-20mA | Analog Input 4 Configurable (default = speed trim I/P) |
| X12/06 | AOUT1 | ±10V (10V=100%speed) | Analog Output 1 Configurable (default = speed feedback O/P) |
| X12/07 | AOUT2 | ±10V (10V=200% torque) | Analog Output 2 Configurable (default = torque feedback O/P) |
| X12/08 | +10V REF | +10V | 10V reference for analog i/o. Load 10mA maximum |
| X12/09 | -10V REF | -10V | 10V reference for analog i/o. Load 10mA maximum |
| DIGITAL I/O | | | |
| X15/01 | DIN1 | 0 or 24V | Configurable Digital Input 1 (default = Jog) |
| X15/02 | DIN2 | 0 or 24V | Configurable Digital Input 2 (default = Run) |
| X15/03 | DIN3 | 0 or 24V | Configurable Digital Input 3 (default = Stop) |
| X15/04 | DIN4 | 0 or 24V | Configurable Digital Input 4 (default = Reverse) |
| X15/05 | DIN5 | 0 or 24V | Configurable Digital Input 5 (default = Torque mode) |
| X15/06 | DIN6 | 0 or 24V | Configurable Digital Input 6 (default = Unassigned) |
| X15/07 | DIN7 | 0 or 24V | Configurable Digital Input 7 (default = Unassigned) |
| X15/08 | DIN8/DOUT1 | 0 or 24V | Configurable Digital Input/output (default : digital input = Running) |
| X15/09 | DIN9/DOUT2 | 0 or 24V | Configurable Digital Input/output (default : digital input = Zero Speed) |


890SD Control Terminals

| Terminal | Name | Range | Description |
|------------------------------|----------------|-----------------------------------|---|
| SAFE TORQUE OFF (STO) | | | |
| X11/01 | STO A | To disable STO: connect to X14/03 |  <p>To use the STO feature, the user must read and fully understand chapter 6 (Safe Torque Off) of the Engineering Reference Manual.</p> |
| X11/02 | STO 0V | To disable STO: do not connect | |
| X11/03 | STO B | To disable STO: connect to X14/03 | |
| X11/04 | STO 0V | To disable STO: connect to X14/04 | |
| X11/05 | STO STATUS -ve | To disable STO: do not connect | |
| X11/06 | STO STATUS +ve | To disable STO: do not connect | |



890CS Control Terminals

| Terminal | Name | Range | Description |
|--------------------|------------------|-----------|--|
| ANALOG I/O | | | |
| X01/01 | +24V | 24V | 24V input from Auxiliary power supply |
| X01/02 | +24V | 24V | 24V aux supply output to downstream drives |
| X01/03 | 0V | 0V | 0V aux supply output to downstream drives |
| X01/04 | 0V | 0V | 0V input from Auxiliary power supply |
| X02/05 | AOUT | 0-10V | Indication of Output Power or Input Current, selected by AOUT MODE. Scaled so that 5V is 100% nominal power or current |
| X02/06 | 0V OUT | 0V | 0V for AOUT |
| DIGITAL I/O | | | |
| X02/01 | +24V OUT | 24V | Supply for digital inputs |
| X02/02 | DIGIN 1 | - | Future use |
| X02/03 | ENABLE | 0 or 24V | Sequencing input to start the CS unit |
| X02/04 | AOUT MODE | 0 or 24V | Selects nature of AOUT: 0V = Output Power, 24V = Input Current |
| X04/01 | PRE TRIP WARNING | Contact 1 | Closed = HEALTHY, Open = WARNING |
| X04/02 | PRE TRIP WARNING | Contact 1 | Closed = HEALTHY, Open = WARNING |
| X04/05 | HEALTH | Contact 2 | Closed = HEALTHY, Open = TRIP |
| X04/06 | HEALTH | Contact 2 | Closed = HEALTHY, Open = TRIP |



Appendix D: Electrical Ratings

| 890CS Common Bus Supply | | | | | |
|---|-----|------------|---------|-------|-------|
| Output current must not be exceeded under steady state operating conditions. Operating voltage is 208V to 500V ±10%. Output overload 150% overload for 60 seconds. Prospective short circuit current : Frame B 65kA, Frame D 100kA. | | | | | |
| FRAME B : 32A AC rms Input Current (nominal power 15kW) | | | | | |
| 890CS/5/0032B | | | | | |
| Model Number | | | | | |
| Nominal Operating Voltage | Vac | 208/230 | 380/415 | 460 | 500 |
| Output Power | | 7.5kW/10HP | 15kW | 25HP | 18kW |
| Input Current | A | | | 32 | |
| Continuous RMS Output Current | A | | | 40 | |
| Dynamic Brake Current Rating | A | 20 | 20 | 20 | 20 |
| FRAME B : 54A AC rms Input Current (nominal power 30kW) | | | | | |
| 890CS/5/0054B | | | | | |
| Model Number | | | | | |
| Nominal Operating Voltage | Vac | 208/230 | 380/415 | 460 | 500 |
| Output Power | | 15kW/20HP | 30kW | 45HP | 37kW |
| Input Current | A | | | 54 | |
| Continuous RMS Output Current | A | | | 65 | |
| Dynamic Brake Current Rating | A | 40 | 40 | 40 | 40 |
| FRAME D : 108A AC rms Input Current (nominal power 60kW) | | | | | |
| 890CS/5/0108D | | | | | |
| Model Number | | | | | |
| Nominal Operating Voltage | Vac | 208/230 | 380/415 | 460 | 500 |
| Output Power | | 30kW/40HP | 60kW | 90HP | 75kW |
| Input Current | A | | | 108 | |
| Continuous RMS Output Current | A | | | 135 | |
| Dynamic Brake Current Rating | A | 75 | 75 | 75 | 75 |
| FRAME D : 162A AC rms Input Current (nominal power 90kW) | | | | | |
| 890CS/5/0162D | | | | | |
| Model Number | | | | | |
| Nominal Operating Voltage | Vac | 208/230 | 380/415 | 460 | 500 |
| Output Power | | 45kW/60HP | 90kW | 135HP | 110kW |
| Input Current | A | | | 162 | |
| Continuous RMS Output Current | A | | | 200 | |
| Dynamic Brake Current Rating | A | 100 | 100 | 100 | 100 |

890CD Common Bus Drive

Motor power, input current and output current ratings must not be exceeded under steady state operating conditions. Vector Mode 150% overload for 60 seconds. Servo Mode 200% overload for 4 seconds.

FRAME B Input currents listed at 320V DC, 560V DC and 650V DC assuming total source impedances of 400 μ H, 800 μ H and 800 μ H respectively.

| Model Number | 890CD/2/0003B | 890CD/2/0005B | 890CD/2/0007B | 890CD/2/0011B | 890CD/2/0016B |
|-----------------------------------|---------------|---------------|---------------|---------------|---------------|
| Nominal Supply Voltage | Vdc 320 | | | | |
| Motor Power | 0.55/0.75 | 1.1/1.5 | 1.5/2 | 2.2/3 | 4/5 |
| Input Current - Vector Mode | A 4.2 | A 7.6 | A 9.3 | A 15.2 | A 22.2 |
| Output Current - 3kHz Vector Mode | A 3 | A 5.5 | A 7 | A 11 | A 16.5 |
| Output Current - 4kHz Servo Mode | A 2.2 | A 4 | A 6 | A 8 | A 12 |
| Model Number | 890CD/5/0002B | 890CD/5/0003B | 890CD/5/0004B | 890CD/5/0006B | 890CD/5/0006B |
| Nominal Supply Voltage | Vdc 560 | | | | |
| Motor Power | 0.55kW | 1.1kW | 1.5kW | 2.2kW | 3Hp |
| Input Current - Vector Mode | A 2.9 | A 5 | A 6.6 | A 8.6 | A 7.2 |
| Output Current - 3kHz Vector Mode | A 2 | A 3.5 | A 4.5 | A 6 | A 5 |
| Output Current - 4kHz Servo Mode | A 1.5 | A 2.5 | A 3.5 | A 4 | A 4 |
| Model Number | 890CD/5/0010B | 890CD/5/0012B | 890CD/5/0016B | 890CD/5/S016B | 890CD/5/S016B |
| Nominal Supply Voltage | Vdc 560 | | | | |
| Motor Power | 4kW | 5.5kW | 7.5kW | 7.5kW | 10Hp |
| Input Current - Vector Mode | A 14.1 | A 16.8 | A 22.2 | A 24* | A 21.2* |
| Output Current - 3kHz Vector Mode | A 10 | A 12 | A 16 | A - | A - |
| Output Current - 4kHz Servo Mode | A 6 | A 9 | A 12 | A 16 | A 14 |

* Values are for "Input Current - Servo Mode".

890CD Common Bus Drive continued

Motor power, input current and output current ratings must not be exceeded under steady state operating conditions. Vector Mode 150% overload for 60 seconds. Servo Mode 200% overload for 4 seconds.

FRAME C Input currents listed at 320V DC, 560V DC and 650V DC assuming total source impedances of 400 μ H, 800 μ H and 800 μ H respectively.

| Model Number | Vdc | 890CD/2/0024C | 890CD/2/0030C |
|-----------------------------------|-------|---------------|---------------|
| Nominal Supply Voltage | Vdc | 320 | |
| Motor Power | kW/HP | 5.5/7.5 | 7.5/10 |
| Input Current - Vector Mode | A | 31 | 39 |
| Output Current - 3kHz Vector Mode | A | 24 | 30 |
| Output Current - 4kHz Servo Mode | A | 24 | 30 |
| Model Number | Vdc | 890CD/5/0024C | 890CD/5/0030C |
| Nominal Supply Voltage | Vdc | 560 | 560 |
| Motor Power | kW/HP | 11kW | 15kW |
| Input Current - Vector Mode | A | 33 | 43 |
| Output Current - 3kHz Vector Mode | A | 24 | 30 |
| Output Current - 4kHz Servo Mode | A | 20 | 25 |

FRAME D Input currents listed at 560V DC or 650V DC assuming a total of 190 μ H source impedance.

| Model Number | Vdc | 890 CD/5/0039D | 890CD/5/0045D | 890/5/0059D |
|-----------------------------------|-------|----------------|---------------|-------------|
| Nominal Supply Voltage | Vdc | 560 | 560 | 560 |
| Motor Power | kW/HP | 18.5kW | 22kW | 30kW |
| Input Current - Vector Mode | A | 44 | 51 | 66 |
| Output Current - 3kHz Vector Mode | A | 39 | 45 | 59 |
| Output Current - 4kHz Servo Mode | A | 35 | 38 | 50 |

Appendix E: Compliance

A comprehensive guide to product compliance is available in the full product manual.

Warning Where there is a conflict between EMC and safety requirements personnel safety shall always take precedence.

Operation of this equipment requires detailed installation and operation instructions provided in the installation/operation manual intended for use on this product. This information is provided on the CD ROM included in the container this device was packaged in. It should be retained with this device at all times.

Caution: This is a product of the restricted sales distribution class according to IEC 61800-3. It is designated as “professional equipment” as defined in EN61000-3. Permission of the supply authority shall be obtained before connection to the low voltage supply.

In a domestic environment this product may cause radio interference in which case supplementary mitigation measures may be required.

This equipment contains electrostatic discharge (ESD) sensitive parts. Observe static control precautions when handling, installing and servicing this product.

EMC Emissions

Radiated Emissions comply with EN61800-3 category C1, C2 and C3 when installed in accordance with instructions in Chapter 4 / 5 refer to “mounting the unit”.

Conducted Emissions comply with EN61800-3 category C3 without external filter and category C1 and C2 when fitted with specified external filter.

Immunity complies with the requirement of EN61800-3, for equipment intended for use in the second environment.


EMC Connections

For compliance with the EMC requirements, the “0V/signal ground” is to be separately earthed. When a number of units are used in a system, these terminals should be connected together at a single, local earthing point.

Control and signal connections should be made with screened cables, with the screen connected only at the VSD end. However, if high frequency noise is still a problem, earth screen at the non VSD end via a 0.1µF capacitor.

Note: Connect the control and signal screens (at the VSD end) to the VSD protective earth point, and not to the control board terminals.

Motor cables should have a 360° bond to ensure a low impedance connection, as per the figure below;



Planning Cable Runs

- ◆ Use the shortest possible motor cable lengths.
- ◆ Use a single length of cable to a star junction point to feed multiple motors.
- ◆ Keep electrically noisy and sensitive cables apart. If this is not possible parallel cable runs should be separated by at least 0.25 meters, for runs longer than 10 meters, separation should be increased proportionally.
- ◆ Sensitive cables should cross noisy cables at 90°.
- ◆ Never run sensitive cables close or parallel to the motor, dc link and braking chopper circuit for any distance.
- ◆ Never run supply, dc link or motor cables in the same bundle as the signal/control and feedback cables, even if they are screened.
- ◆ Ensure EMC filter input and output cables are separately routed and do not couple across the filter.

